

# Quickstart Guide

# **SL-15**

## 1–2NM+ Solar Marine Lantern

- 🗇 Sealite is a global manufacturer of marine aids to navigation.
- We employ leading mechanical, optical, hardware & software engineers to create innovative products to service the needs of our customers worldwide, and offer the widest range of solar-powered LED lanterns in the marketplace.
- Sealite Pty Ltd has been manufacturing lanterns for over 25 years, and particular care has been taken to ensure your lantern gives years of service.
- As a commitment to producing the highest quality products for our customers, Sealite has been independently certified as complying with the requirements of ISO 9001:2015 quality management system.



#### Quickstart!

- 1. Remove the SL-15 Lantern from the packaging.
- 2. Check if Lantern is switched ON (Using steps below)
- 3. The SL-15 is set to a Flash Code of **0.3 seconds ON & 2.7 seconds OFF (Switch Position 'A' in Flash Code Table)**
- 4. If the SL-15 lantern is preset to the **ON** position it is currently in **Sleep Mode**. To activate, expose the lantern to **30 seconds** of sunlight.
- 5. To check lantern is working, cover the lantern in darkness for at least 30 seconds.
- 6. If you wish to alter the Flash Code please follow the steps below (Adjusting the Flash Code), otherwise proceed to install your lantern.
- 7. Position the lantern in your desired location and secure, utilising the 4 x holes in the flange. Ensure the lantern is bolted to an even, flat surface.

### Turning Lantern ON and Adjusting the Flash Code

- 1. Remove the 4 x battery cover screws and lift the cover and battery out of the compartment to expose the adjustment plug.
- 2. Unscrew the adjustment plug.
- 3. Ensure internal lantern switch is set in the **ON** position.
- 4. Using a small flat bladed screwdriver adjust the Flash Code to the desired setting. (Refer to Flash Code Table)
- 5. Cover the lantern, in darkness, for at least **30 seconds** to activate the lantern sensor. Make sure the lantern is flashing correctly.
- 6. Uncover the lantern and wait at least **30 seconds** to make sure the lantern turns off in daylight.
- 7. Insert the adjustment plug and replace the battery.
- 8. Replace the cover and secure using the 4 x screws. Do Not over tighten screws.

#### **Charging the Battery**

New lanterns should be left in the sun for 1-2 days to ensure battery is charged before placing in service. Please note, lantern will re-charge even when switch is turned to 'OFF' position.


#### **Preferred Installation Location**

For best lantern performance, ensure solar modules are not covered and are in clear view of the sky with no shadows.



## **Quickstart Guide**

Diagram



SL-15

**SL-15** 

#### **Flash Code Table**

SWITCH	FLASH SETTING		DUTY
POSITION	ON (sec)	OFF (sec)	CYCLE
0	Steady On		100%
1	0.5	1.0	33%
2	0.5	3.5	12.5%
3	1.0	3.0	25%
4	0.5	5.5	8.5%
5	0.3	0.7	30%
6	0.3 (On), 0.7 (Off), 0.3, 0.7, 0.3, 0.7, 0.3, 15.7		6.5%
7	0.3	1.7	15%
8	0.3	2.2	12%
9	0.5	2.0	20%
Α	0.3	2.7	10%
В	0.5	2.5	16.5%
С	0.7	2.3	23.5%
D	0.5	4.5	10%
E	1.0	4.0	20%
F	Custom Flash Code Position - (on request)		

SL-15\_QSG\_EN\_V1-1

To Download Full Installation Manual and Reference to more options of this product Goto: http://www.sealite.com/products/marine-lanterns/1-2nm-solar-marine-lantern Or scan the QR code >





Sealite Pty Ltd Australia t: +61 (0)3 5977 6128 Sealite Asia Pte Ltd Singapore t: +65 6829 2243 Sealite United Kingdom Ltd UK t: +44 (0) 1502 588026 Sealite USA LLC USA t: +1 (603) 737 1311

sealite.com info@sealite.com

We believe technology improves navigation™